

PMML-1: Pad Mount Transformer Lid Lifter

Features & Benefits:

- Eliminate back strains / injuries
- Eliminate face exposure to flash
- Up to 5x easier to lift transformer door
- Non-conductive handle
- 90 lb. magnet securely connects to metal covers
- Debris shield to cover magnet when not in use
- Compact design for easy storage

Attach with lip & magnet Lift with back straight Lower with back straight



Debris shield



Open position



Extend position



Storing position



Safer Solution – Eliminate Back Strains/Injuries



Unfold PMLL Handle to 90 Degrees



Uncover Magnet and Position
Onto Transformer Lid.



- 3) Rotate Outer Handle Counter-Clockwise;
- 4) Pull Outer Handle to Extend;
- 5) Rotate Outer Handle Clockwise to Lock in Place



***Not designed for rusted
shut lids. For difficult
transformers to open –
use the handle in the non-
extended position (See #3)***



With PMLL Secured and Lower Lip Engaged , Lift Safely!
To disengage magnet, see next page.

To disengage magnet from transformer lid, rotate handle downward.



Rotate tool body until pivot point
contacts transformer lid.



With handle parallel to transformer
lid, magnet will disengage.